



## Procedures for Charging the Battery



### Step 1.

Plug the 12V transformer into a 120V power source, then, plug the other end into the post.

### Step 2.

Press the blue colored on-off button, located at the bottom side of control panel.

Allow the battery to fully charge for a minimum eight hours. This will activate the memory and store all the program settings, in case you have to unplug the umbrella for short periods.

**Note:** If you plan to store or unplug the umbrella for more than 2 weeks, release the on-off button so to save its battery. When you plug in the umbrella again, it is possible that you will have to re-program the settings.