

# **Primo Super U92200 Series Electrical Troubleshooting Guide**

**Warning: always unplug any appliance before attempting any repairs.**

- 1. Remove the lower post and make sure the wire plug is firmly connected to the socket on the upper frame.**
- 2. Check the Transformer. Make sure the power cord is plugged into an 110V Power Supply. Make sure the output cord is properly inserted into the umbrella frame lower pole Power Socket.**
- 3. Remove and inspect the Power Switch. Inspect the wires on the back of the switch. Make sure the wires are firmly attached to the connectors on the switch. Check the condition of the wires. No cuts or frays.**
- 4. Remove and inspect the Power Socket on the lower pole. Make sure the wires are firmly attached to the connectors on the Socket. Check the condition of the wires. No cuts or frays.**
- 5. Unscrew the vent top cap. Remove the fabric from the frame. Remove the cover from the upper hub and inspect the wires. Make sure all the wires are attached to the proper connectors. Tighten all the screws in the hub. Check the condition of the wires. No cuts or frays.**

